MG400滑轨套件发货清单
MG400 Sliding Rail Kit Shipping List

滑 轨 (Sliding Rail)

直线模组
Linear module

伺服电机
Servo motor

伺服驱动器
Servo driver

配 件 (Attachments)

❶ 动力线束
Power wiring harness

❷ 控制线束
Control wiring harness

❸ MG400急停组件延长线束
Extended wiring harness of MG400 emergency stop unit

❹ 伺服急停端子
Emergency stop terminal of servo

❺ DI线束
DI wiring harness

❻ DO线束
DO wiring harness

❼ 网线
Network cable

# MG400滑轨套件安装说明
MG400 Sliding Rail Kit Assembly Instructions

## 1. 将滑轨固定到工作台上 (Fix the slide rail on the workbench)

方法一 (Method 1)：

M4 螺钉 x 4
M4 Screws x 4

M4 螺钉 x 4
M4 Screws x 4

M5 螺钉 x 12
M5 Screws x 12

200mm 200mm 100mm

200mm 200mm

88 mm

❶ 将滑轨放置到工作台上，拧出上盖螺钉
Place the slide rail on the workbench;
Unscrew the upper cover.

❷ 拆开滑轨上盖
Remove the upper cover of the slide rail;

❸ 锁紧滑轨螺钉，安装滑轨上盖
Tighten the screws;
Install the upper cover of the slide rail.

方法二 (Method 2)：

连接件 x 6
Connector x 6

M4 螺钉 x 12
M4 Screws x 12

145 mm

30mm 455.5mm 30mm 455.5mm 30mm

M5 螺钉 x 12
M5 Screws x 12

连接件 x 6
Connector x 6

145 mm

30mm 455.5mm 30mm 455.5mm 30mm

❶ 将滑轨放置到工作台上，将安装连接件固定在滑轨上
Place the slide rail on the workbench;
Fix the installation connector on the slide rail.

❷ 锁紧螺钉
Tighten the screws.

2. 安装MG400 (Install MG400)

❶ 动力线束
Power wiring harness

❷ 控制线束
Control wiring harness

❸ MG400急停组件延长线束
Extended wiring harness of MG400 emergency stop unit

❹ 伺服急停端子
Emergency stop terminal of servo

❺ DI线束
DI wiring harness

❻ DO线束
DO wiring harness

❼ 网线
Network cable

❽ 编码器&动力线束
Encoder & Power harness

❾ MG400电源适配器（不在包装内）
MG400 power cord adapter (Not in the package)

❶ 将MG400安装到滑轨上
Install MG400 on the slide rail.

❸ 连接MG400线缆
Connect the MG400 cables.

DOBOT MG400

LAN 1 LAN 2 USB1 USB2 ENC ON/OFF E-STOP

电脑连接网线
Connect the computer to the network

❷ 连接伺服驱动器线缆
Connect the servo driver cables.

MG400急停开关(不在包装内)
MG400 emergency stop button
(Not in the package)

3. 通过DobotStudio2020控制MG400 (Connect the robot by DobotStudio2020)